

## INSTALLATION INSTRUCTIONS FOR ADJURE'S BIG CITY LED LIGHTS

ADJURE OFFERS DOT COMPLIANT LED REPLACEMENT TURN SIGNALS TO FIT BOTH THE FLAT AND FOOTBALL HARLEY DAVIDSON TURN SIGNAL HOUSINGS. STOCK HARLEY DAVIDSON HAS 3-WIRE AMBER (RUN/TURN) IN FRONT AND 2-WIRE AMBER (TURN ONLY) IN THE REAR. IF YOU WANT TO CHANGE YOUR REAR TURN SIGNALS INTO RUN/TURN/BRAKE, YOU MUST CHANGE THE LENS COLOR TO RED AND THE BEST WAY TO DO THIS IS TO ALSO ORDER AND INSTALL OUR P/N# K48590 (RUN/TURN/BRAKE CONTROLLER). NOTE: WHEN USING LED'S AS A TURN SIGNAL YOU MUST ALWAYS USE A "LOAD EQUALIZER" P/N#K48100 TO MAKE THEM WORK PROPERLY.

### INSTALLATION: COVERS BOTH FLAT AND FOOTBALL HOUSINGS

- 1) REMOVE THE LENSES FROM YOUR STOCK TURN SIGNALS BY REMOVING THE 2 SCREWS ON EACH SIDE OF THE LENS.
- 2) REMOVE THE BULB BY PUSHING IN AND TURNING COUNTER CLOCKWISE.
- 3) INSERT INTO THE LIGHT SOCKET THE PLUG ON YOU NEW LED'S BY PUSHING IT IN AND TURNING IT CLOCKWISE.
- 4) SET THE LENS ON THE HOUSING AND REPLACE THE SCREWS.  
TO CONNECT THE LOAD EQUALIZER:
  - 1) THERE ARE 3 WIRES CONNECT THE BLACK TO A GOOD GROUND AND ONE OF THE WIRES TO ANYWHERE IN THE LEFT SIDE TURN SIGNAL SYSTEM AND THE OTHER WIRE TO ANYWHERE IN THE RIGHT SIDE TURN SIGNAL SYSTEM.

NOTE: FOR TECH TIPS CALL 888-966-9333