

NSSAMO INSTALLATION INSTRUCTIONS

- 1- MEASURE THE OUTSIDE DIAMETER OF THE TUBE THAT THE CLAMP IS GOING TO FIT.
- 2- SELECT THE CORRECT SIZE INSERT (SUPPLIED), THE SMALLEST IS FOR 1", MIDDLE SIZE FOR 1 1/8" AND THE LARGEST FOR 1 1/4" TUBE.
- 3- ADJUST THE HOLLOW STUD TO THE DESIRED LENGTH AND LOCK IN PLACE USING THE HOLLOW ALLEN SCREW (SUPPLIED) FROM THE BACKSIDE.
- 4- INSTALL THE CLAMP WITH THE CORRECT INSERT MAKING SURE THE WIRE EXIT HOLE IS POINTING DOWN (LOCATED ON THE LARGER SIDE OF THE CLAMP), DO NOT TIGHTEN THE CLAMP BOLTS YET.
- 5- INSTALL MARKER LIGHT ONTO THREADED HOLLOW STUD, POSITION THE LIGHT AS REQUIRED AND SECURE USING THE JAM NUT INSIDE THE BODY AND THE CHROME LOCKNUT BETWEEN THE CLAMP AND THE LIGHT.
- 6- TIGHTEN THE CLAMP BOLTS ONCE THE LIGHT IS CORRECTLY POSITIONED; (ADJURE RECOMMENDS THE USE OF A DROP OF BLUE THREAD LOCKER).
- 7- THREAD THE WIRES FROM YOUR MARKER LIGHT THROUGH THE HOLLOW STUD AND OUT OF THE EXIT HOLE IN THE CLAMP.
- 8- ROUTE THE WIRES AS DESIRED AND MAKE THE APPROPRIATE ELECTRICAL CONNECTIONS.
- 9- CHECK THE LIGHT FOR FUNCTION AND TIGHTNESS.
- 10- REPEAT PROCEDURE FOR THE SECOND LIGHT AND CLAMP.