

INSTALLATION INSTRUCTIONS FOR CORVETTE SIDE MARKERS
PART NUMBERS: CV103SM-C & CV103SM-R

THE STOCK LENSES ON THE C5 FOR SOME REASON HAVE A PINK COLOR. WE HAVE TWO WAYS TO GO. ADJURE OFFERS DOT COMPLIANT CLEAR AND RED DIAMOND CUT SIDE MARKERS. THEY REALLY MAKE A DIFFERENCE. BECAUSE OF THE LENS DESIGN THEY LOOK MUCH RICHER, LIKE THEY BELONG ON THE CAR AND NOT LIKE AN ADD-ON.

INSTALLATION:

- 1) REMOVE THE LEFT TAILLIGHT BY REMOVING THE 2 SCREWS IN THE LENS.
- 2) THERE ARE 2- 7/16 FLEX LOCK NUTS HOLDING THE SIDE MARKERS ON. REMOVE BOTH NUTS THEN REMOVE THE STOCK MARKER LIGHT.
- 3) REPLACE WITH YOUR NEW ADJURE MARKER LIGHT. USE THE WIRE, BULB AND SOCKET FROM YOUR STOCK LIGHT.
- 4) REPEAT THE PROCEDURE ON THE OTHER SIDE.