

## INSTALLATION INSTRUCTIONS FOR HBM001 HEADLIGHT BUCKET MOUNT

MOST ALL MOUNTS INCLUDING THIS ONE WILL NEED A 3/8-16 MOUNTING BOLT. IN ORDER FOR YOU TO BUY THE RIGHT SIZE BOLT MEASURE THE DEPTH OF THE THREADS IN THE MOUNT AND THE THICKNESS OF THE BOTTOM TRIPLE TREE. THIS BOLT WILL BE INSTALLED THROUGH THE BOTTOM OF THE TRIPLE TREE AND SHOULD THREAD INTO THE MOUNT AT LEAST ¼". BEFORE YOU TIGHTEN MAKE SURE THE BLOCK MOUNT IS STRAIGHT.

THE MOUNT THAT SHOULD BE ALREADY ATTACHED TO THE BOTTOM OF YOUR BUCKET, WILL HAVE TWO EARS THAT WILL GO OVER THE OUTSIDE OF THE BLOCK MOUNT AND THEN INSTALL A PINCH BOLT. ADJUST YOUR BUCKET BEFORE YOU TIGHTEN THE PINCH BOLT.