

INSTALLATION INSRUCTIONS FOR HBM003, HBM006 & HBM007
PILLAR MOUNTS

WITH EACH OF THESE MOUNTS YOU WILL NEED TO MEASURE THE THICKNESS OF YOUR BOTTOM TRIPLE TREE THEN THE THREAD DEPTH ON THE MOUNT. YOU WILL NEED TO PURCHASE A 3/8-16 BOLT THE CORRECT LENGTH. INSERT THE BOLT THRU THE BOTTOM OF THE TREE HOLE AND THREAD IT INTO THE MOUNT. MAKE SURE THE MOUNT IS STRAIGHT BEFORE TIGHTENING.

THERE WILL BE TWO EARS ON THE HEADLIGHT BUCKET BRACKET. PLACE THE ROUND THREADED SPACER IN BETWEEN THE EARS ON THE BUCKET BRACKET THEN PLACE THE TWO EARS BETWEEN THE EARS ON THE MOUNT. INSERT THE SCREWS AND SNUG. ADJUST YOUR LAMP THEN TIGHTEN THE SCREWS TIGHT ENOUGH SO THE BUCKET WILL NOT MOVE.