

## ADJURE SPOT LIGHT BUCKET MOUNTING INSTRUCTIONS

### INVENTORY LIST PER BUCKET FROM TOP TO BOTTOM

#### TO BE MOUNTED ON THE INSIDE PORTION OF THE BUCKET

- 1- STAINLESS STEEL STUD 3/8-16
- 1- HEX NUT
- 1- LOCK WASHER
- 1- STUD GUIDE

#### TO BE MOUNTED ON THE OUTSIDE PORTION OF THE BUCKET

- 1- CHROME STAND-OFF
- 1- CHROME CHAMFERED ADJUSTER WASHER
- 1- CHROME ADJUSTER WASHER
- 1- FLAT WASHER
- 1- LOCK NUT

- 1-INSTALL THE LOCK NUT ON ONE END OF THE STUD UNTIL STUD IS EVEN WITH TOP OF NUT THEN STACK THE LOCK WASHER THEN FLAT WASHER.
- 2-PUSH STUD THROUGH THE MOUNTING HOLE ON YOUR LIGHT BAR THEN STACK THE ADJUSTER WASHER THEN THE CHAMFERED ADJUSTER WASHER THEN ADD THE STAND-OFF.
- 3-SET BUCKET ON STUD MAKING SURE THE INDEX PIN LINES UP.
- 4-SLIDE THE STUD GUIDE OVER THE STUD SO THE INDEX HOLE LINES UP WITH THE INDEX PIN, NOW SLIDE ON THE LOCK WASHER THE GROUND WIRE ON THE LAMP THEN THE NUT.