

SWING ARM FLUSH MOUNT PIVOT SHAFT: P/N PS0001

- 1) RAISE REAR WHEEL OFF THE GROUND.
- 2) REMOVE EXISTING PIVOT SHAFT.
- 3) SCREW SHORT NUT ON SHORT END OF PIVOT SHAFT.
- 4) INSERT NEW PIVOT SHAFT THROUGH FRAME FROM LEFT SIDE OF THE BIKE.

SCREW LONG NUT ONTO PIVOT SHAFT AND TORQUE TO 55 FT POUNDS.