

"B" MOTOR MOUNT DRESS-UP BOLTS: P/N PS0002

- 1) REMOVE LOWER MOTOR MOUNT BOLT.
- 2) SCREW NUT ON ½" LONG THREADED END OF LONG STUD.
- 3) FROM RIGHT SIDE OF BIKE, INSERT LONG STUD THROUGH FRAME AND MOTOR.
SCREW SECOND NUT ON AND TORQUE TO 50 FT POUNDS.
- 4) REMOVE UPPER MOTOR MOUNT BOLT.
- 5) SCREW NUT ON ½" LONG THREADED END OF SHORT STUD.

**FROM RIGHT SIDE OF BIKE, INSERT SHORT STUD THROUGH FRAME AND MOTOR.
SCREW SECOND NUT ON AND TORQUE TO 50 FT POUNDS.**